

VERIFY THAT ALL PARTS ARE PROVIDED BEFORE BEGINNING THE ASSEMBLY.

PARTS LIST

ITEM	PART NUMBER	DESCRIPTION	QTY
2	8002113	SMSCR-TH PHIL-A 10-32X3/4 B0	11
	1954402	DRAFT DIVERter SS MCO-G-5L/R	1
1	1954401	DRAFT DIVERter GG MCO-G-5L/R	1

INSTRUCTIONS

- 1 - PLACE ITEM #1 ON THE MAIN TOP OF THE UNIT KEEPING THE PERFORATED SECTION FACING THE FRONT OF THE UNIT.
- 2 - ALIGN ITEM #1 TO THE EXISTING FLUE BOX USING THE EXISTING MOUNTING HOLES.
- 3 - USING THE SCREWS PROVIDED, FASTEN ITEM #1 TO THE FLUE BOX OF THE UNIT.
- 4 - ONCE ITEM #1 IS MOUNTED, USE THE HOLES PROVIDED TO DRILL (7) 9/64" DIA HOLES TO BE USED AS MOUNTING HOLES TO THE MAIN TO OF THE UNIT.

