

VERIFY THAT ALL PARTS ARE PROVIDED BEFORE BEGINNING THE ASSEMBLY.

**PARTS LIST**

ITEM	PART NUMBER	DESCRIPTION	QTY
4	8002113	SMSCR-TH PHIL-A 10-32X3/4 BO	14
3	1953604	FLUE STACKING PLATE MCO-G-5L/R	1
2	1953698	FLUE STACK W/A	1
1	1953603	FLUE BOX COVER BTM DECK LT/RT	1

**INSTRUCTIONS**

- 1 - FIRST, WHILE FACING THE BACK OF THE UNIT, DETERMINE WHICH SIDE OF THE MOTOR TO RUN THE FLUE STACK W/A (ITEM #2) TO CONNECT THE FLUE BOX BOTTOM DECK TO THE FLUE BOX TOP DECK. REMOVE THE CORRECT FLUE COVER PLATE FROM THE TOP DECK.
- 2 - ATTACH ITEM #3 TO THE INSIDE OF ITEM #1 USING THE SCREWS PROVIDED.
- 3 - LOCATE THE CORRECT MOUNTING HOLES IN THE BOTTOM FLUE BOX AND ATTACH ITEM #1 USING THE SCREWS PROVIDED.
- 4 - BEGIN CONNECTING THE FLUE BOXES BY INSERTING ITEM #2 THROUGH THE OPENING IN THE TOP FLUE BOX AND PULLING IT BACK DOWN OVER THE FLANGES ON ITEM #3.
- 5 - USING ONE OF THE SCREWS PROVIDED, FASTEN THE FLUE STACK W/A (ITEM #2) TO ITEM #4.

