

INSTRUCTIONS

- STEP 1 - INSTALL (ITEM 1) DOOR GASKET FRAME TOP/BOTTOM AS SHOWN USING (8) SCREWS PROVIDED.
- STEP 2 - INSTALL (ITEM 2) DOOR GASKET FRAME LT/RT AS SHOWN USING (6) SCREWS PROVIDED.
- STEP 3 - FASTEN REMAINING (6) SCREWS INTO VISIBLE HOLES IN RIGHT SIDE AND BOTTOM OF DOOR.
- STEP 4 - MAKE SURE ALL SCREWS ARE TIGHT.
- STEP 5 - INSTALL (ITEM 3) DOOR GASKET BY LOCKING INTO GASKET FRAME.
- STEP 7 - CLEAN UP ANY METAL FILINGS FROM OVEN AREA.

