


# GARLAND

MODEL NUMBERS:

36ER30B, 36ES30B,  
36ET30B, 36EC30B,  
36ER30BB, 36ES30BB,  
36ET30BB

Top Sections



REF. #	PART NO.	DESCRIPTION	36ER30B	36ES30B	36ER30BB	36ES30BB
			36ET30B	36EC30B	36ET30BB	36ET30BB
1.	1217999 1217998	Flue Assembly - Painted Flue Assembly - S/S		1 OPT.		1 OPT.
2.	1218699 1218698	Main Top Assembly - Painted Main Top Assembly - S/S		1 OPT.		2 OPT.
3.	1220001 1220003	L/H Body Side - Painted L/H Body Side - S/S		1 OPT.		2 OPT.
4.	1218799	Main Front Assembly		1		2
5.	1216798	Drip Tray Assembly Complete		1		2
6.	1105101	Drip Tray Handle Only		1		2
7.	1114100	Grill Rack		1		2
8.	1216899	Carriage Assembly		1		2
9.	1216803	Handle Only (Included in above)		1		2
10.	1039903	Roller Bearing		6		12
11.	1220595	Track Frame Assembly		1		2
12.	1220700	Switch Panel		1		2
13.	1160797 1160800	Pilot Lamp Assembly Resistor (460V Only)		2 2		4 4
14.	1010702	Dial		2		4
15.	1010705 1010706 1010701	Switch (208V-240V) OBSOLETE - N/L/A Switch (208V-240V) Direct Replacement Switch (460V Only)		2 2 2		4 4 4
16.	1217600	Ratchet Support		1		2
17.	1093902	Handle		1		2
18.	1217098	Rod and Cam Assembly		1		2
19.	1039903	Roller		1		2
20.	1217799	Broiler Handle Assembly		1		2
21.	1082901	Spring Hook		1		2
22.	1113400	Spring		1		2
23.	1217199	Rack Arm Support		1		2
24.	1218100	Main Back		1		2
25.	1217299 1218399	Element Frame Assembly Reflector Pan Assembly		2 2		4 4
26.	1160600	Element Jumper		6		12
27.	1032300 1032301	Element (208V) Element (240V-460V)		8 8		16 16
28.	1220000 1220002	R/H Body Side - Painted R/H Body Side - S/S		1 OPT.		2 OPT.
29.	9004500	Garland Logo		1		2

(\*SPECIFY FINISH ON ALL PAINTED ITEMS)