

CONTROLS

Display Codes – Prompts

OFF	Oven is in the OFF mode.
Lo	Oven cavity temperature is below set point.
Hi	Oven cavity temperature is above set point.
LOAD	Oven cavity has reached set temperature - prompt for operator to load oven.
SETb	Oven has defaulted to factory set back temperature.
Auto	Oven is in 'auto cool down' mode and will remain in auto until cavity temp is below 150°F.
OPEn	Display will toggle from 'OPEN' to 'DOOR' to prompt for operator to open door when unit is in cool down.
Door	
Door	In auto cool down mode, door is open past 30° or in cooking mode, door is opened.
Prob	Open or shorted cavity sensing probe.
HELP	Oven cavity has exceeded 560°F.
CodE	475 controllers, prompt for operator to enter access code from programming 4-2-7-5.
SHLF	475 controllers, prompt for operator to select shelf to be programmed.
PR-2	475 controllers, prompt for operator to program the profile for the second cook time if required.
PRE	475 controllers, prompt for operator to set pre-alarm if required.
HoLd	475 controllers, prompt for operator set the hold temperature the oven is in programmed HOLD temperature.
FAn	475 controller, prompt for operator to se fan speed.
DonE	Oven has completed its cooking cycle.
Cool	Door is open less then 30° in cool down mode.