



## Garland Frybaskets (Gas Units)

Model	Part Number	Size	Mount	Type
G22-18F	G02700-3	11 x 4 3/4 X 4 3/4	Side	Twin RH
	G02700-4	11 X 4 3/4 X 4 3/4	Side	Twin LH
	G02701-2	10 3/4 X 9 3/16 X 4 3/4	Side	Single
70-40/ M70	803-0024	16 3/4 x 8 3/4 X 6	Front	Twin
56-40	<b>803-0017</b>	<b>17 X 17 1/8 X 5 3/4</b>	<b>Front</b>	<b>Single</b>
35-40/ 35-280/ M35	803-0271	13 1/4 X 5 7/8 X 5 1/2	Front	Twin
	<b>803-0015</b>	<b>14 X 11 1/8 X 4 3/8</b>	<b>Front</b>	<b>Single</b>
GD-15F	803-0019	11 X 5 3/8 X 4 1/8	Front	Twin
	803-0014	11 1/8 X 10 3/4 X 4 3/8	Front	Single

## Garland Frybaskets (Electric Units)

Model	Part Number	Size	Mount	Type
10-70F/ 36ES21	G2432-1	16 X 8 X 5 5/8	Side	Twin
	G2432-2	16 X 8 X 5 5/8	Side	Twin
10-31F/SF/ E18/S18/ 36ES11	G02698-1	13 X 5 X 5 1/2	Side	Twin
	G02698-2	13 X 5 X 5 1/2	Side	Twin
	G02699-1	13 X 10 X 5 1/2	Side	Single
10-31BL/ E18BL/ 36ES11BL	<b>G01075-1-8</b>	<b>13 X 5 X 5 3/4</b>	<b>Front</b>	<b>Twin</b>