

Honeywell (Gray) S8600H to Johnson G777MHA-1

Terminal to Terminal Conversion Guide



From **Honeywell**

1. MV

2. MV/PV

3. PV

4. GND (Burner)

5. 24V GND

6. 24V

9. Spark

To **Johnson**

3. MV

Ground

1. PV

Ground

Ground

2. THS

