

### **Setting Setback Feature**

**To set or change the setback settings, press and hold the SETBACK key for two seconds. The TEMP LED will light and a temperature will be displayed. Set the temperature using the dial, then press the SET key. The TEMP LED will go out and the TIME LED will light ("Time" is factory set at 0). Set the time using the dial, then press the SET key. Press the SET key one more time to exit programming.**

**Note: To disable the setback function, set the temperature to 250° F (121°C) and the time to zero.**