




STW286A 120v shown with the Power Switch Off while plugged in.




STW286A 120v shown with the Power Switch On, and the Fan Switch in the Off Position




STW286A 120v shown with the 2 Griddle Zones Calling for Heat




STW286A 120v shown with the Fan Switch in Cook Position and the Door Open




STW286A 120v shown with the Fan Switch in Cook Position and the Door Closed



STW286A 120v shown with the Fan Switch in Cook, Door Closed, & Oven calling for heat.




STW286A 120v shown with the Hot top Ignition Switch Depressed (and valve activated).



STW286A fan switch in Cool Down Position with the door closed





STW286A fan switch in Cool Down Position with the door open