

FACTORY PROGRAMMING INSTRUCTIONS FOR TJ CINNAMON'S

THE UNIT MUST BE ON BEFORE BEGINNING TO PROGRAM

USE THE DIAL TO CHANGE THE NUMBERS ON THE DISPLAY FOR TIME AND TEMPERATURE

MANUAL BAKE

1. PRESS SET KEY TO PROGRAM THE TEMPERATURE.
2. PRESS SET KEY AGAIN TO PROGRAM THE FAN.
3. PRESS SET KEY AGAIN TO PROGRAM THE TIME.
4. PRESS SET KEY AGAIN TO END PROGRAM.

PRE-PROGRAMMED BUTTONS

1. PRESS AND HOLD PROG KEY FOR THREE (3) SECONDS - ALL THE PRODUCT KEY LEDs LIGHT.
2. CODE WILL BE DISPLAYED. PRESS 4-2-7-5 AND THE START/CANCEL KEY. **PROD** WILL BE DISPLAYED.
3. PRESS THE PRODUCT KEY #1. ONCE THE PROGRAMMING FOR PRODUCT KEY #1 IS COMPLETED, REPEAT STEPS 1 & 2 AND PRESS THE APPROPRIATE PRODUCT KEY TO BEGIN PROGRAMMING THE NEXT BUTTON. THE PROGRAMMING FOR EACH PRODUCT KEY IS SHOWN BELOW. ONCE IN PROGRAM MODE YOU HAVE 10 SECOND TO PRESS A BUTTON OR THE CONTROL WILL EXIT PROGRAM MODE.

START/CANCEL BY PRESSING THIS BUTTON YOU CAN TOGGLE BETWEEN THE AVAILABLE OPTIONS IN PROGRAMMING.

SET BY PRESSING THIS BUTTON YOU ADVANCE TO THE NEXT FEATURE IN PROGRAMMING.

PRODUCT KEY	SHLF	TIME	PRE	TEMP	FAN	ST / FL
		:01 min		270 °F	LO	
1	YES	27 MIN	:00	270 °F	LO	FL
2	YES	26 MIN	:00	270 °F	LO	FL
3	YES	15 MIN	:00	325 °F	LO	FL
4	YES	22 MIN	:00	270 °F	LO	FL
5	YES	:01 min	:00	270 °F	LO	FL
6	YES	:01 min	:00	270 °F	LO	FL
7	YES	2 MIN	:00	270 °F	LO	FL
8	YES	:01 min	:00	270 °F	LO	FL
9	YES	2 MIN	:00	325 °F	LO	FL

MANUAL BAKE

**** NOTE ** A SOLID COLON INDICATES THE TIMER WILL COUNTDOWN IN MINUTES AND SECONDS, WHILE A FLASHING COLON INDICATES HOURS AND MINUTES**